## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provided).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
Α	BACK	1	1 PC	
В	SEAT	1	1 PC	
С	FRONT LEG	1	2 PCS	
D	ARM	1	2 PCS	
Е	CUSHION	1	1PC	
F	PILLOW	1	1PC	

HARDWARE LIST (BOX : 1)				
ITEM	DESCRIPTION		QTY	
1	JCBC Bolt M6 x 55mm	<del></del>	2 PCS	
2	JCBC Bolt M6 x 45mm	<b>*********</b> €	2 PCS	
3	JCBC Bolt M6 x 35mm	<b></b> ⊕	1 PC	
4	M6 FLAT WASHER	0	9 PCS	
5	M6 SPRING WASHER	0	9 PCS	
6	WOOD SCREW M4 x 35mm	-mm-A	4 PCS	
7	M4 ALLEN KEY (BALL SHAPE)	<b>\</b>	1 PC	
8	WOOD DOWELM8 x30MM		2 PCS	
9	WOOD BUTTON DIA 13.5MM	0	2 PCS	
10	JCBC BOLT M6 x60mm	<b></b> 6	8 PCS	











