

# SW 8029 - F / Q / K

**1.** Attach the headboard post (P1) to the headboard (P2). You will need to use hardware:

- A = 4pcs
- D = 4pcs
- E = 8pcs

**2.** Attach the side rail (P3) to the headboard (P2) and footboard (P4) using hardware:

- B = 8pcs
- D = 8pcs
- E = 4pcs
- F = 8pcs

**3.** Fix the adjuster (I) to the support leg (P6) using hardware :  
I = 2pcs

Attach the support legs (P6) to the centre rail (P5) and footboard (P4) using hardware :  
C = 2pcs

Attach the centre rail (P5) to the headboard (P2) and footboard (P4) using hardware :  
G = 2pcs








**4.** Lay the slats (P7) between the side rail (P3) using hardware :  
G = 28pcs (F)  
or  
G = 30pcs (Q/K)

Attach the slats (P7) to the centre rail (P5) using hardware :  
G = 3pcs










## WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

## PART LIST

P1		Headboard Post = 2pcs
P2		= 1pcs
P3		= 2pcs
P4		= 1pcs
P5		= 1pcs
P6		= 2pcs
P7		Bed Slats (F) = 14pcs Bed Slats (Q/K) = 15pcs

## HARDWARE LIST

<b>A</b>		M6 x 100mm JCBC	4pcs
<b>B</b>		M6 x 60mm JCBC	8pcs
<b>C</b>		M6 x 50mm JCBC	2pcs
<b>D</b>		BARREL NUT	12pcs
<b>E</b>		Ø8 x 35mm WOOD DOWEL	12pcs
<b>F</b>		WOODEN PLUG	12pcs
<b>G</b>		M4 X 25mm SCREW (F) M4 X 25mm SCREW (Q/K)	33pcs 35pcs
<b>H</b>		ALLEN KEY M4	1pcs
<b>I</b>		ADJUSTER	2pcs

