MODEL: BBT6534 A1 QUEEN BED

ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
A	HEADBOARD	1 PC	
В	FOOTBOARD	1 PC	
С	SIDE RAIL	2 PCS	
D	CENTER RAIL	1 PC	
E	CENTER SUPPORT	2 PCS	
F	CENTER SUPPORT LEG	3 PCS	
G	BED SLAT	26 PCS	
Н	BED LEG	4 PCS	

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 20mm	amaa⊏()	8 PCS
2	JCBB BOLT M8 x 30mm	aaaaaaa	8 PCS
3	M6 FLAT WASHER	0	8 PCS
4	M6 SPRING WASHER	0	8 PCS
5	WOOD SCREW M3.5 x 16mm	~~~~~ €	8 PCS
6	WOOD SCREW M4 x 25mm	400000 €	8 PCS
7	BED SLAT SIDE FITTER		26 PCS
8	BED SLAT CENTER FITTER	\Diamond	13 PCS
9	M4 ALLEN KEY (BALL SHAPE)		1 PC
10	M5 ALLEN KEY (BALL SHAPE)	J	1 PC

