ASSEMBLY INSTRUCTIONS MODEL: BBT6482 (W1550 x L2070) BED

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

- CAUTIONS: 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.
 - 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

| PART LIST | | | |
|-----------|--------------------|--------|--|
| ITEM | DESCRIPTION | QTY | |
| Α | HEADBOARD | 1 PC | |
| В | FOOTBOARD | 1 PC | |
| С | SIDE RAIL | 2 PCS | |
| D | CENTER RAIL | 1 PC | |
| E | CENTER SUPPORT | 2 PCS | |
| F | CENTER SUPPORT LEG | 3 PCS | |
| G | BED SLAT | 26 PCS | |
| Η | BED LEG | 4 PCS | |

| PART LIST | | | |
|-----------|--------------------------|--------|--|
| ITEM | DESCRIPTION | QTY | |
| 1 | JCBB BOLT M8 x 30mm | 8 PCS | |
| 2 | JCBB BOLT M8 x 40mm | 4 PCS | |
| 3 | M8 FLAT WASHER | 4 PCS | |
| 4 | M8 SPRING WASHER | 4 PCS | |
| 5 | WOOD SCREW M3.5 x 16mm ◆ | 8 PCS | |
| 6 | WOOD SCREW M4 x 25mm | 8 PCS | |
| 7 | BED SLAT CENTER FITTER | 13 PCS | |
| 8 | BED SLAT SIDE FITTER | 26 PCS | |
| 9 | M5 ALLEN KEY | 1 PC | |

