MODEL: BBT6483 (1550 x 2070) BED

ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	HEADBOARD LEG (L&R)	2 PCS	
С	FOOTBOARD	1 PC	
D	SIDE RAIL	2 PCS	
E	CENTER RAIL	1 PC	
F	CENTER SUPPORT	2 PCS	
Ġ	CENTER SUPPORT LEG	3 PCS	
Н	BED SLAT	26 PCS	
Ī	BED LEG	2 PCS	
]	HEADBOARD SUPPORT WOOD	2 PCS	
K	HEADBOARD SUPPORT RAIL	1 PC	

		1		
	PART LIST			
DESCRIPTION		QTY		
ICBB BOLT M8 x 30mm	**************************************	8 PCS		
ICBC BOLT M8 x 50mm		6 PCS		
ICBC BOLT M8 x 60mm		4 PCS		
ICBC BOLT M8 x 70mm	·	2 PCS		
M8 FLAT WASHER	0	10 PCS		
M8 SPRING WASHER	0	10 PCS		
WOOD SCREW M3.5 x 16mm	√	8 PCS		
BED SLAT SIDE FITTER		26 PCS		
BED SLAT CENTER FITTER	\Diamond	13 PCS		
M5 ALLEN KEY (BALL SHAPE)		1 PC		
	CBB BOLT M8 x 30mm CBC BOLT M8 x 50mm CBC BOLT M8 x 60mm CBC BOLT M8 x 70mm M8 FLAT WASHER M8 SPRING WASHER WOOD SCREW M3.5 x 16mm MED SLAT SIDE FITTER MED SLAT CENTER FITTER	CBB BOLT M8 x 30mm CBC BOLT M8 x 50mm CBC BOLT M8 x 60mm CBC BOLT M8 x 70mm (8 FLAT WASHER WOOD SCREW M3.5 x 16mm ED SLAT SIDE FITTER ED SLAT CENTER FITTER		



