









INSTRUCTION FOR DC-231

Step	PICTURE	Notes
Step 1		<p>place the seat and feet upside down. Then, start with the first screw (please note that 4 of the metal bars do not seem to be aligned with the holes when you first putting them together)</p>
Step 2		<p>When the 1st screw is tightened up, work on the 2nd screw at the hole facing diagonally from the first hole.</p>
Step 3		<p>After the 1st and the 2nd screws have been tightened, work on the 3rd one. The right way to align the 3rd metal bar with the pre-drilled hole is to push the metal bar towards the hole so that they match up</p>
Step 4		<p>When 3 screws have been tightened up, the last metal bar will appear to be not lining up with the hole. The next step is to push the metal bar harder and hold it towards matching with the hole.</p>
Step 5		<p>You may need additional hands to help pushing the metal bar towards the hole as you need to apply enough forces to maneuver the last piece of metal bar</p>
Step 6		<p>Then, find the plastic floor protectors from a small plastic bag in the box (8 pieces provided)</p>
Step 7		<p>Slide the plastic cap onto the metal bar from the side (please do not force the cap from top by hammer)</p>
Step 8		<p>These chairs are available to be seated</p>