



配件代号	数量	配件
A	8	
C	10	
M	32	30*8mm
N	30	40*5mm
	1	28mm
X	10	
Y	1	12cm
Z	4	

Instruction&Step:

1, Put C on the beds, with Z.

2, Fix the headboard and bed slat with A, Put Z on.

3, Fix the bedend and slats with A, put Z on.

4, Put Y as the legs for the slats on

☆ Note: The 32 bolts for part M, 32 screws are not in the hardware kit. They are pre-screwed on frame in the holes.

