



B-86#

Accessory Code	Quantity	Accessory
A	8 Pcs	
C	10 Pcs	
M	32 Pcs	30*8mm
N	30 Pcs	30*5mm
	1 Pcs	
X	10 Pcs	Black cotton pad Diameter 28mm
Y	1 Pcs	Height 22cm
Z	4 Pcs	

Steps Please refer to the picture for specific operations

- ① Use angle iron C to fix the headboard and the bedside, bed end; and stick on the cotton pad X
- ② Use angle iron A to fix the headboard and the bedside; and install the feet Z
- ③ Use angle iron A to fix the bed and the bedside; and install the feet Z
- ④ **Install the stand Y and the slat**
Slat foot can be adjusted in accordance with the slat

