

Steps	Please find the specific operations on the sketch map	
1	Use the A type angle irons to fix four corners	
2	Fix the platoon skeleton using C type angle irons on the four corners	
3	Install platoon skeleton's feet	

Note: The 34 bolts for part M, 34 screws are not in the hardware kit. They are pre-screwed on frame in the holes.

Accessory code	Number	Accessory picture
Α	8 Pcs	0000
С	10 Pcs	0.0
М	34 Pcs	30*8mm
N	30 Pcs	®
	1 Pcs	
		(L)

