



B-177#

Accessory Code	Quantity	Accessory
A	8 PCS	30*8mm
C	10	30*8mm
D	32	30*8mm
E	4	30*8mm
F	50	40*3mm
G	1	Height 19cm
H	1	Height 19cm
I	10	Diameter 28mm

Steps	Steps
①	Please refer to the picture for specific operations Use the wood screw F to fix the headboard, bedside and bed end. Install the accessories B and stick on the cotton pad H
②	Use angle iron A and install the feet E the bedside; and install the feet E
③	Use angle iron A and screw D to fix the bedside and bed end; and install the feet E
④	Install the stand H and the slat

