



1. After you opened the package, twist out the socket



2. Remove Part B and C from A



3. Twist and detach Part B and C



4. Insert Part B into Part A



5. Insert the wire into part A, pull out from part B



6. Screw lose the two screws located above the holes



7. Insert the wire into the holes, tighten the screws above



8. Pull Part D into Part B



9. Twist Part C and B tight



10. Insert Part B and C into Part A Pull the wire



11. Twist the socket back to the shade



12. Tightened the stand