ASSEMBLY INSTRUCTIONS

PAGE 1 OF

parts on a clean and flat soft surface to prevent from being scratched. Be sure all parts are complete, before you assemble. Place all wooden furniture Read this instruction carefully. See hardware and furniture part list for guidance. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
 Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY

| PAKILISI DESCRIPTION QTY HEADBOARD 1 PC FOOTBOARD 1 PC SIDE RAIL 2 PCS CENTER RAIL 1 PC CENTER SUPPORT 2 PCS BED LEG 4 PCS CENTER SUPPORT LEG 2 PCS BED SLAT 26 PCS HEADBOARD BESIDE (L&R) 2 PCS | | I HE/ | Н ВЕС | G CEN | F BEC | E CEN | D CEN | C SID | B FOO | A HE | ITEM | |
|--|---|----------------------|----------|--------------------|---------|----------------|-------------|-----------|-----------|-----------|-------------|-----------|
| | | ADBOARD BESIDE (L&R) | BED SLAT | CENTER SUPPORT LEG | BED LEG | CENTER SUPPORT | CENTER RAIL | SIDE RAIL | FOOTBOARD | HEADBOARD | DESCRIPTION | PARI LIVI |
| | | | 26 PCS | 2 PCS | 4 PCS | 2 PCS | 1 PC | 2 PCS | 1 PC | 1 PC | ΩΤΥ | |
| | • | | | | | | | | | | | |

| | | PART LIST | | |
|---|------|------------------------|----------|--------|
| | ITEM | DESCRIPTION | | ΩΤΥ |
| | 1 | JCBC BOLT M6 x 35mm | () () | 8 PCS |
| | 2 | JCBC BOLT M6 x 45mm | | 8 PCS |
| | 3 | JCBB BOLT M8 x 30mm | 6 | 4 PCS |
| _ | 4 | Wood Screw M4 x 25mm | -mm=) | 12 PCS |
| | 5 | Wood Screw M3.5 x 16mm | -emme) | 8 PCS |
| | 6 | BED SLAT SIDE FITTER | ♦ | 26 PCS |
| | 7 | BED SLAT CENTER FITTER | | 13 PCS |
| | 8 | M4 ALLEN KEY | ٢ | 1 PC |
| | 9 | M5 ALLEN KEY | ٢ | 1 PC |
| | 10 | M6 FLAT WASHER | 9 | 8 PCS |





