ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not $FULLY$ - $TIGHTEN$ the nut or nut bolt until all nut or bolt is ready asse	mbed.
---	-------

- 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
- 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

	PART LIST	
ITEM	DESCRIPTION	QTY
Α	CUSHION	1 PC
В	FRONT LEG	2 PCS
С	BACK LEG	2 PCS

	HARDWARE LIST	_	
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 20mm	ccccccccc	8 PCS
2	M6 FLAT WASHER	0	8 PCS
3	M6 SPRING WASHER		8 PCS
4	M4 ALLEN KEY (BALL SHAPE)	\	1 PC

