## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Hammer (not provider).

PART LIST			
DESCRIPTION	QTY		
HEADBOARD	1 PC		
HEADBOARD WING (L&R)	2 PCS		
HEADBOARD SUPPORT	1 PC		
FOOTBOARD	1 PC		
SIDE RAIL (L&R)	2 PCS		
CENTER RAIL	1 PC		
CENTER SUPPORT LEG	3 PCS		
LEG	4 PCS		
BED SLAT	1 SET		
SIDE RAIL SUPPORT	2 PCS		
	DESCRIPTION HEADBOARD HEADBOARD WING (L&R) HEADBOARD SUPPORT FOOTBOARD SIDE RAIL (L&R) CENTER RAIL CENTER SUPPORT LEG LEG BED SLAT		

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 45mm	((((((((((((((((((((((((((((((((((((((	18 PCS
2	JCBB BOLT M8 x 50mm		16 PCS
3	M6 SPRING WASHER	0	10 PCS
4	M6 FLAT WASHER	0	8 PCS
5	M8 SPRING WASHER	0	16 PCS
6	WOOD DOWEL M8 x 30mm		4 PCS
7	WOOD DOWEL M10 x 30mm		8 PCS
8	M4 ALLEN KEY (BALL SHAPE)		1 PC
9	M5 ALLEN KEY (BALL SHAPE)		1 PC
10	WOOD SCREW M4 x 38mm		9 PCS
11	M8 FLAT WASHER	0	16 PCS







