ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembly.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

PART LIST				
ITEM	DESCRIPTION	QTY		
A	HEADBOARD	1 PC		
В	FOOTBOARD	1 PC		
С	SIDE RAIL	2 PCS		
D	CENTER RAIL	1 PC		
E	CENTER SUPPORT	2 PCS		
F	CENTER SUPPORT LEG	3 PCS		
G	BED SLAT	26 PCS		
Н	BED LEG	4 PCS		

1		HARDWARE LIST	
1	ITEM	DESCRIPTION	QTY
1	1	JCBC BOLT M6 x 20mm COMMUNIC €	8 PCS
1	2	M6 FLAT WASHER	8 PCS
ł	3	M6 SPRING WASHER	8 PCS
┨	4	WOOD SCREW M3.5 x 16mm	8 PCS
┨	5	WOOD SCREW M4 x 25mm	8 PCS
┨	6	BED SLAT SIDE FITTER	26 PCS
\mathbf{I}	7	BED SLAT CENTER FITTER	13 PCS
\mathbf{I}	8	WOOD SCREW M4 x 20mm	2 PCS
l	9	M4 ALLEN KEY (BALL SHAPE)	1 PC
	10	M5 ALLEN KEY (BALL SHAPE)	1 PC



