ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

- CAUTIONS: 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.
 - 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.

PART LIST ITEM DESCRIPTION QTY CUSHION BACK 1pc CUSHION SEAT 1pc ARM (L) 1pc ARM (R) 1pc FRONT RAIL 1pc

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBB Bolt M8 x 70mm	 (-)	6pcs
2	Wood Dowel M10 x 40mm		2pcs
3	M8 Bran Nut	8	2pcs
4	Wood Button Dia 18.5mm	0	6pcs
5	M5 Allen Key (Ball Shape)	<u> </u>	1pc

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.







