



**ASSEMBLY INSTRUCTION**  
**MODEL : 8117 / TV CABINET**

Before you begin, please follow assembly instruction carefully.  
 Then follow them step by step.


**STEP 1**




**STEP 2**




**STEP 3**




**STEP 4**



**STEP 5**



**STEP 6**



**HARDWARE LIST**

NO	DESCRIPTION	QTY
I	JCBCW SCREW M6 x 45	4pcs
II	M4 ALLEN KEY	1pc
III	CAP SMALL	4pcs

IV	M8 x 30 PLASTIC DOWEL	18pcs
V	Q-FIT	4sets
VI	Q-FIT (small)	8sets
VII	NAIL	10pcs
VIII	PVC NAIL WITH PIN	5pcs



IX	PLASTIC LEG & SCREW M3.5 x 16	1sets
X	L BRACKET & SCREW M3.5 x 12	3sets

**CAUTION:**

To clean use soft, dry cloth. Do not use detergent or chemicals  
 Avoid contact with water and direct sunlight.  
 To be assembled on a soft, dry, clean and smooth surface.

**ORDERING REPAIR PARTS**

In order to obtain smooth and rapid service when ordering repair parts,  
 please give full attention to the following of PART NUMBER.



# COMPLETE SET

NO	DESCRIPTION	QTY
A	LEFT SIDE WRAPPING (Front)	01
B	LEFT SIDE WRAPPING (Back)	01
C	RIGHT SIDE WRAPPING (Front)	01
D	RIGHT SIDE WRAPPING (Back)	01
E	LEFT SIDE	01
F	RIGHT SIDE	01

NO	DESCRIPTION	QTY
G	TOP	01
H	CENTRE VERTICAL	02
I	LOWER SHELF	01
J	LOWER SHELF SUPPORT	02
K	TOP SUPPORT	01
L	BACK	01