

# ASSEMBLY INSTRUCTIONS


MODEL : PCH 101SK-36


## TABLE

Before you begin, Please follow Assembly Instruction carefully . Then follow them step by step.

| PART LIST |            |      |
|-----------|------------|------|
| A         | TABLE TOP  | 1 PC |
| B         | TABLE LEGS | 4PCS |

| HARDWARE LIST |  |       |
|---------------|--|-------|
| C             |  HEX SCREW      | 8-PCS |
| D             |  FLAT WASHER    | 8 PCS |
| E             |  HEX WRENCH     | 1 PC  |
| F             |  SPRING WASHER | 8 PCS |



IMPORTANT NOTE : PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.

FIX THE TABLE LEGS (B) TO THE CORNER BLOCK WITH ALLEN BOLT (C) , SPRING WASHER (D) & FLAT WASHER (E). THEN TIGHTEN THE ALLEN BOLT (C) BY USING THE ALLEN KEY.

