ASSEMBLY INSTRUCTIONS

Follow the figure to start assembling. Be sure all parts are complete, before you assemble. Place all wooden furniture Read this instruction carefully. See hardware and furniture part list for guidance. parts on a clean and flat soft surface to prevent from being scratched.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY

							•		
H	G	F	П	D	С	В	Þ	ITEM	
BED LEG	BED SLAT	CENTER SUPPORT LEG	CENTER SUPPORT	CENTER RAIL	SIDE RAIL	FOOTBOARD	HEADBOARD	DESCRIPTION	PART LIST
2 PCS	39 PCS	6 PCS	3 PCS	2 PCS	2 PCS	1 PC	1 PC	QTY	
5	؞ؗؖ	, -	6	5	4	ü	~	<u>- - - - - - - - - - </u>	

			ľ		
1 PC	٢	MS ALLEN KEY	5	2947	ED LEG
1. R	٢	M4 ALLEN KEY	9	3 7 6	
25	Sec.	WOOD SCREW M4 x 32mm	8	30 pCs	ED CI AT
2700	Œ	25mm SOFA LEG	7	SOA 9	ENTER SUPPORT LEG
26 PCS	0	BED SLAT CENTER FITTER	6	3 PCS	ENTER SUPPORT
26 PGS	0	BED SLAT SIDE FITTER	5	2 PCS	ENTER RAIL
12 PCS	- 12 PCS	WOOD SCREW M3.5 x 16mm	4	2 PCS	DE RAIL
4 PCS		JCBC BOLT M6 x 20mm	ω	2	OTBOARD
4 PCS		JCBB BOLT M8 x 30mm	2	7	EADBOARD
4 PCS		JCBB BOLT M8 x 40mm	1	3	DESCRIPTION
QTY		DESCRIPTION	TEM	OTY	DESCRIPTION
		PART LIST			PART LIST

์ฮ

