ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

			•					w	•
ᄑ	ଦ	F	E	ס	С	В	Α	ITEM	
BED LEG	BED SLAT	SUPPORT LEG	CENTER SUPPORT LEG	CENTER RAIL	SIDE RAIL	FOOTBOARD	HEADBOARD	DESCRIPTION	
4 PCS	24 PCS	2 PCS	2 PCS	1 PG	2 PCS	1 PC	1 PC	QTY	
									_
	ı		1	1	- 1	- 1		-d I	

7- []			PARTILIST		
CRIPTION	QŢY	TEM	DESCRIPTION		위
JARD	<u>고</u>	!	TOP POIT NO WOOM	200 8 000	S DCS
7,00	3	F	שלים מסבו ויוס א במוווים	ا	8
JAKU	7	٦			ر م
VT1	2 PCc	7	JCBC DOLL 190 X JOHN	٥	18
ř	1	J	MA ALIEN VEV	_	3
RAIL	1 공	u	MIN ACCOUNTS		7
BT FG	2 62	4	M5 ALLEN KEY	٢	1 공
1		٦	פביי כי איז כיויים ביויים	S	24 000
CT LEG	2 PCS	U	BED SLAT SIDE FILLER	8	24 PC
1	37 PCC	ת	BED SI AT CENTER FITTER	\$ 12 PG	12 00

