Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.


2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST		
ITEM	DESCRIPTION	QTY
Α	HEADBOARD	1 PC
В	HEADBOARD LEG (L&R)	2 PCS
U	FOOTBOARD	1 PC
D	SIDE RAIL	2 PCS
ш	CENTER RAIL	2 PCS
F	CENTER SUPPORT	3 PCS
G	CENTER SUPPORT LEG	6 PCS
H	BED SLAT	39 PCS
I	BED LEG	2 PCS
j	HEADBOARD SUPPORT WOOD	2 PCS
K	HEADBOARD SUPPORT RAIL	1 PC

PART LIST			
ITEM	DESCRIPTION	QTY	
1	JCBB BOLT M8 x 30mm	8 PCS	
2	JCBC BOLT M8 x 50mm	6 PCS	
3	JCBC BOLT M8 x 60mm	4 PCS	
4	JCBC BOLT M8 x 70mm	2 PCS	
5	M8 FLAT WASHER 🔘	10 PCS	
6	M8 SPRING WASHER	10 PCS	
7	WOOD SCREW M3.5 x 16mm	12 PCS	
8	BED SLAT SIDE FITTER	26 PCS	
9	BED SLAT CENTER FITTER	26 PC5	
10	M5 ALLEN KEY (BALL SHAPE)	1 PC	



ASSEMBLY INSTRUCTIONS

