Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	HEADBOARD LEG (L&R)	2 PCS	
C	FOOTBOARD	1 PC	
ם	SIDE RAIL	2 PCS	
E	CENTER RAIL	1 PC	
F	CENTER SUPPORT	2 PCS	
G	CENTER SUPPORT LEG	3 PCS	
Н	BED SLAT	24 PCS	
I	BED LEG	2 PCS	
J	HEADBOARD SUPPORT WOOD	2 PCS	
K	HEADBOARD SUPPORT RAIL	1 PC	

PART LIST			
ITEM	DESCRIPTION		QTY
1	JCBB BOLT M8 x 30mm	• • • • • • • • • • • • • • • • • • •	8 PCS
2	JCBC BOLT M8 x 50mm	6900000	10 PCS
3	M8 FLAT WASHER	9	10 PCS
4	M8 SPRING WASHER	•	10 PCS
5	WOOD SCREW M3.5 x 16mm	~~~~€	8 PCS
6	BED SLAT SIDE FITTER		24 PCS
7	BED SLAT CENTER FITTER	\Diamond	12 PCS
8	M5 ALLEN KEY (BALL SHAPE)		1 PC
9	PVC BLACK WASHER	•	2 PCS



