






















PARTS & HARDWARESLIST


A		1 PC			1 PC
					1 PC
B		1 PC	J		1 PC
C		1 PC	K		1 PC
D		1 PC			
E		1 PC	L		1 PC
F		1 PC	1		14 PCS
G		1 PC	2		6 PCS
H		1 PC	3		14 PCS
I		1 PC	4		12 PCS
		1 PC	5		1 PC

ASSEMBLY INSTRUCTION


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



STEP 7

