

LEGS INSTALLATION INSTRUCTION

ITEM NO.:TSF-8145-Wing Chair



Leg position of the chair



front leg*2PCS



back leg*2PCS



Metal Gasket 8 pcs



Screw 8pcs



Spring Washer 8pcs



Wrench 1pcs

