





SOFT, DRY CLOTH



CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE



DO NOT USE KNIFE

ASSEMBLY INSTRUCTION


MODEL : TV 834127

DESCRIPTION : TV CABINET


HARDWARE

A	B	C	D	E	F	G	H	J
A1 A2	16MM	38MM	65MM			G1 G2 G3	H1 H2	
WOOD DOWEL 8 X 25 1X20 1X4	CB SCREW M3.5X16MM 1X52	CB SCREW M4X38MM 1X24	CB SCREW M4X65MM 1X8	NAIL 5/8 1X50	L KEY 1X1	MINIFIX 5654+5546 8 SETS	QUICKFIT CAP 3 SETS	5038 PVC LEG (SILVER) 1X5


PART LIST




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10



STEP 11



STEP 12



COMPLETED

