



ASSEMBLY INSTRUCTION

MODEL : TV 838063

DESCRIPTION : TV CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	
	WOOD DOWEL 8 X 25 1X24	CB SCREW M3.5X16MM 1X36	CB SCREW M4X38MM 1X30	CB SCREW M4X65MM 1X20	POWER NAIL 5/8 1X74	ALLEN KEY 1X1	MINIFIX 5654 + 5546 14 SETS	MINIFIX CAP 1X6	HANDLE 1106 -96 S/S (METAL) 1X3	HANDLE SCREW M4X35MM 1X6	DRAWER SLIDE 16" 3 SETS

