ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance.

Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.

Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY

PART LIST			
ITEM	DESCRIPTION	QTY	
Α	HEADBOARD	1 PC	
В	HEADBOARD LEG (L)	1 PC	
С	HEADBOARD LEG (R)	1 PC	
D	HEADBOARD SUPPORT RAIL	1 PC	
E	FOOTBOARD	1 PC	
F	SIDE RAIL (L)	2 PCS	
G	SIDE RAIL (R)	2 PCS	
Н	CENTER SUPPORT WOOD	4 PCS	
I	CENTER LEG	4 PCS	
J	BED LEG	4 PCS	

HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 20mm	aaaa ⊏()	4 PCS
2	JCBC BOLT M6 x 30mm	««««««—()	16 PCS
3	JCBC BOLT M6 x 35mm	((((((((((((((((((((((((((((((((((((((12 PCS
4	JCBB BOLT M8 x 50mm	((((((((((((((((((((((((((((((((((((((6 PCS
5	M6 SPRING WASHER	0	20 PCS
6	M6 FLAT WASHER	0	20 PCS
7	M8 SPRING WASHER	0	6 PCS
8	M8 FLAT WASHER	0	6 PCS
9	M4 ALLEN KEY (BALL SHAPE)	ا	1 PC
10	M5 ALLEN KEY (BALL SHAPE)	Ĵ	1 PC
11	SHEET METAL (VMB 3076)		2 PCS





