Read this instruction carefully. See hardware and furniture part list for guidance.

Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched.

Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY

•	PART LIST			
1	ITEM	DESCRIPTION	QTY	
	Α	HEADBOARD	1 PC	
	В	HEADBOARD LEG (L)	1 PC	
	С	HEADBOARD LEG (R)	1 PC	
	D	HEADBOARD SUPPORT RAIL	1 PC	
	E	FOOTBOARD	1 PC	
	F	SIDE RAIL (L)	2 PCS	
	G	SIDE RAIL (R)	2 PCS	
	Н	CENTER SUPPORT WOOD	4 PCS	
	I	CENTER LEG	4 PCS	
	J	BED LEG	4 PCS	

HARDWARE LIST					
ITEM	DESCRIPTION		QTY		
1	JCBC BOLT M6 x 20mm	<b>@</b>	4 PCS		
2	JCBC BOLT M6 x 30mm	<b>((((((((((((((((((((((((((((((((((((</b>	16 PCS		
3	JCBC BOLT M6 x 35mm		12 PCS		
4	JCBB BOLT M8 x 50mm	aaaaaaaaa —()	6 PCS		
5	M6 SPRING WASHER	0	20 PCS		
6	M6 FLAT WASHER	0	20 PCS		
7	M8 SPRING WASHER	0	6 PCS		
8	M8 FLAT WASHER	0	6 PCS		
9	M4 ALLEN KEY (BALL SHAPE)		1 PC		
10	M5 ALLEN KEY (BALL SHAPE)		1 PC		
11	SHEET METAL (VMB 3076)		2 PCS		





