

PAGE 1 OF 2



PAGE 2 OF 2




PAGE 1 OF 2

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

	PART LIST			PART LIST		
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION		QTY
А	BACK	1pcs	1	JCBB Bolt M8 x 60mm	••••••••••••••••••••••••••••••••••••••	9pcs
В	SEAT	1pcs	2	JCBB Bolt M8 x 80mm		2pcs
С	ARM	2pcs	3	M8 Flat Washer	0	5pcs
D	FRONT RAIL	1pcs	4	M8 Spring Washer	0	5pcs
			5	Wood Dowel M10 x 40mm	Ø	2pcs
			6	M8 Bran Nut	6	2pcs
			7	Wood Button Dia 18.5mm	Q	6pcs
			8	M5 Allen Key (Ball Shape)	>	1pc
			9	Wood Screw M4 x 50mm		3pcs



PAGE 2 OF 2

