









Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. 3. Keep all hardware parts out of reach of children.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY. Tool needed : Screwdriver & Hammer (not provided).

.	PART LIST				HARDWARE LIST		
	ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY	
	А	CUSHION SEAT	1pc	1	JCBB Bolt M8 x 50mm	4pcs	
	В	FRONT STRETCHER	1pc	2	Wood Screw M4 x 38mm	10pcs	
	С	BACK STRETCHER	1pc	3	M8 Spring Washer	4pcs	
	D	LEG	2pcs	4	Wood Dowel M10 x 30mm	5pcs	
				5	M5 Allen Key (Ball Shape)	1pc	







