


#### **ASSEMBLED DIMENSIONS**





NOTE: THE MAXIMUM WEIGHT THIS PRODUCT CAN HOLD UP TO 25 KGS.

## BC 6132-01


NO.	PART LIST	QTY	NO.	PART LIST	QTY
(A)	RIGHT SIDE PANEL	1	(G)	DRAWER FRONT	2
(B)	LEFT SIDE PANEL	1	(H)	DRAWER RIGHT SIDE PANEL	2
(C)	TOP PANEL	1	(I)	DRAWER LEFT SIDE PANEL	2
(D)	BOTTOM PANEL	1	(J)	DRAWER BACK PANEL	2
(E)	FIXED SHELF	1	(K)	DRAWER BASE	2
(F)	BACK PANEL	1			


### **PARTS LIST**





C





#### BC 6132-01

#### Top Tips before you start!

- 1. Please check that all parts are present before you start the assembly of your furniture.
- 2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.
- 3. For larger items, please ensure that you have sufficent space and people (as indicated on page 1) to assemble your product safely
- 4. We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- 5. For the protection of your furniture, we recommend that the product is placed on a protected surface during assembly to prevent any damage.
- 6. During assembly please take care not to over-tighten any fittings, as this may damage the product.
- 7. Always place the product on a flat, steady and stable surface.
- 8. Do not sit or stand on the product. Do not use the product as a stepladder.
- 9. This product is intended for indoor, household use only as it is non industrial product.
- 10. This product is constructed from re-inforced hollow board. Excessive pressure causes irreparable damage. Please do not kneel on any part of this product during assembly.

#### **Care and Maintenance of your Furniture**


- Please periodically check all fittings and re-tighten as necessary.
- To clean your item, please use a damp cloth and wipe clean.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.
- Please do not place hot items (e.g. hot drinks) directly on to the wood surface.
- Please do not drag and pull your furniture.

BC 6132-01

SPECIAL TIPS FOR FITTING CAM-LOCKS **AND QUICKFIT** 



WHEN FITTING CAMLOCK **ENSURE STARTING POSITION IS CORRECT** BEFORE YOU INSERT CONNECTING QUICKFIT TURN CLOCKWISE UNTIL SECURE






**WRONG** 









Quickfit head needs to be in centre


#### **CAM BOLT**


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)








**Panel** 




























9 / 15















11 / 15













# BC 6132-01






STEP 18





14 / 15

It is recommended that you fit the anti-tip bracket to this item to avoid tipping and causing injury.

#### FITTING OF ANTI-TIP BRACKET







NOTE: Wall fixings are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work). You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used as a diameter greater that the diameter of the mounting hole on the bracket and that the fixing is safe and secure before use.

The screw supplied is to fix the anti-tip strap to the cabinet.

HARDWARE LIST



Anti-Tip Strap - 1pc



M3.5 x 12MM - 1pc