## MODEL : BBT 5158.11 A1 CHAIR

## ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. PART LIST PART LIST Be sure all parts are complete, before you assemble. Place all wooden furniture ITEM DESCRIPTION QTY ITEM DESCRIPTION QTY parts on a clean and flat soft surface to prevent from being scratched. 1 PC А CHAIR BACK JCBC BOLT M6 x 45mm 2 PCS 1 Follow the figure to start assembling. В FRONT LEG 2 PCS 2 JCBC BOLT M6 x 60mm 4 PCS С CUSHION SEAT FRAME 1 PC CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed. 3 JCBC BOLT M6 x 80mm 4 PCS M6 SPRING WASHER 4 0 10 PCS 2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread. ା M6 FLAT WASHER 10 PCS 3. Keep all hardware parts out of reach of children. 5 6 M4 ALLEN KEY 1 PC NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY. STEP 1 STEP 2 STEP 3 STEP 4 **BACK VIEW** 5 6 2

## ASSEMBLY INSTRUCTIONS

## MODEL: 7008T

Read this instruction carefully, remove all wrapping material, staples and straps from the carton. See hardware and furniture part list. For guidance. Be sure you have all wooden furniture parts on a clean and soft surface to prevent from being scratched. Follow the figure to start assembling.

Caution:

- 1. Do not FULLY -TIGHTEN the nut or bolt until all nut or nut bolt is ready to assembled.
- 2. Do not OVER- TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
- 3. Keep all hardware part out of reach of children.

PART LIST			HARDWARE LIST			
No.	DESCRIPTION	QTY	No.	DESCRIPTION		QTY
A	TABLE TOP	1	1	FLAT WASHER 6/19"	0	8
B	TABLE LEG	4	2	SPRING WASHER 6/13"	Ø	8
D			3	JCBC SCREW M6 X 70MM	9	8
			4	M4 ALLEN KEY	<u> </u>	1

