# **ASSEMBLY INSTRUCTIONS**

 $(\mathbf{1})$ 

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton.

See hardware and furniture part list.

For guidance. Be sure you have all wooden furniture parts on a clean and flat soft surface, such as a carpet or rug, to prevent from being scratched. Follow the figure to start assembling.

#### CAUTION :

1. Do not FULLY - TIGHTEN the nut or screw until all is ready to assemble.

2. Do not OVER - TIGHTEN the nut or screw to avoid causing damages to the thread. 3. Keep all hardware part out reach of children.

#### Step 1

Attach part 1 and 2 for all four sides and lock it using hardware A, B, C, and D.

 $(\mathbf{2})$ 

2

### Model no : BW19-02T


 $\widehat{\mathbf{1}}$ 

No	Part List	Qty	No	Description		Qty
1	Table Top	1	A	M5 ALLEN KEY		1
2	Table Leg	4	B	JCBC Screw M8 x 60mm		8
			С	Spring Washer	Q	8

D Flat Washer

8

 $\odot$ 



COMPLETE **ASSEMBLE** 

## ASSEMBLY INSTRUCTIONS

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton.

See hardware and furniture part list.

For guidance. Be sure you have all wooden furniture parts on a clean and flat soft surface, such as a carpet or rug, to prevent from being scratched. Follow the figure to start assembling.

#### CAUTION :

1. Do not FULLY - TIGHTEN the nut or screw until all is ready to assemble.

Do not OVER - TIGHTEN the nut or screw to avoid causing damages to the thread.
Keep all hardware part out reach of children.

### Model no : BW20-17C

No	Part List	Qty
1	Back Rail	1
2	Front Rail	1
3	Center Support	2
4	Side Frame	1
5	Back Rest	1
6	Cushion Seat	1

No	Description	Qty	
Α	M4 ALLEN KEY		1
В	JCBC Screw M6 x 50mm		10
С	Spring Washer	Q	10
D	Wood Dowel 8 x 30mm		4
Е	CSK Screw M4 x 32mm	\$	8

