Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembly.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.


3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


Tool needed: Screwdriver (not provider).


PART LIST				
ITEM	DESCRIPTION	QTY		
A	HEADBOARD	1 PC		
В	FOOTBOARD	1 PC		
C	SIDE RAIL	2 PCS		
D	CENTER RAIL	1 PC		
E	CENTER SUPPORT LEG	3 PCS		
F	BED SLAT	24 PCS		
G	BED LEG	4 PCS		
H	CENTER SUPPORT	2 PCS		
I	HEADBOARD SUPPORT RAIL	1 PC		
J	HEADBOARD BOX (L/R)	2 PCS		
K	HEADBOARD SUPPORT WOOD	2 PCS		


HARDWARE LIST					
DESCRIPTION		QTY			
JCBB BOLT M8 x 30mm	<b>6888888</b> 0□	8 PCS			
JCBC BOLT M6 x 40mm	<b>«</b> ⊕	10 PCS			
JCBB BOLT M8 x 80mm	(MAXMAXIMIX	4 PCS			
M6 Flat Washer	0	10 PCS			
M6 Spring Washer		10 PCS			
M8 Flat Washer	0	4 PCS			
M8 Spring Washer		4 PCS			
WOOD SCREW M3.5 x 16mm		8 PCS			
BED SLAT SIDE FITTER		24 PCS			
BED SLAT CENTER FITTER	$\Diamond$	12 PCS			
M4 ALLEN KEY (BALL SHAPE)		1 PC			
M5 ALLEN KEY (BALL SHAPE)		1 PC			
WOOD SCREW M4 x 20mm	-mm:i)	2 PCS			
	DESCRIPTION JCBB BOLT M8 x 30mm JCBC BOLT M6 x 40mm JCBB BOLT M8 x 80mm M6 Flat Washer M6 Spring Washer M8 Flat Washer WOOD SCREW M3.5 x 16mm BED SLAT SIDE FITTER BED SLAT CENTER FITTER M4 ALLEN KEY (BALL SHAPE) M5 ALLEN KEY (BALL SHAPE)	DESCRIPTION  JCBB BOLT M8 x 30mm  JCBC BOLT M6 x 40mm  JCBB BOLT M8 x 80mm  M6 Flat Washer  M6 Spring Washer  WOOD SCREW M3.5 x 16mm  BED SLAT SIDE FITTER  BED SLAT CENTER FITTER  M4 ALLEN KEY (BALL SHAPE)  M5 ALLEN KEY (BALL SHAPE)			











## MODEL: BBT 3106 NIGHT STAND

## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

PART LIST				
ITEM	DESCRIPTION	QTY		
Α	NIGHT STAND	1 PC		
В	HANDLE	2 PCS		
С	HANDLE SCREW	2 PCS		
D	FLAT WASHER	2 PCS		
Е	DRAWER	2 PCS		

PART LIST				
ITEM	DESCRIPTION	QTY		
1	-			
2	-			

