MODEL : BBT5470 CHAIR

Follow the figure to start assembling.

Tool needed : Screwdriver (not provided).

ASSEMBLY INSTRUCTIONS

BACK

SEAT

ARM

FRONT LEG

CUSHION SEAT

CUSHION BACK

ITEM

А

В

С

D

Е

F

PART LIST

BOX

1

1

1

1

1

1

QTY

1 PC

1 PC

2 PCS


2 PCS

1PC

1PC

DESCRIPTION

HARDWARE LIST (BOX : 1)			
ITEM	DESCRIPTION		QTY
1	JCBC BOLT M6 x 55mm		2 PCS
2	JCBC BOLT M6 x 45mm	 0	2 PCS
3	JCBC BOLT M6 x 35mm	0	1 PC
4	M6 FLAT WASHER	0	9 PCS
5	M6 SPRING WASHER	0	9 PCS
6	WOOD SCREW M4 x 35mm	••••••••••••••••••••••••••••••••••••••	4 PCS
7	M4 ALLEN KEY (BALL SHAPE))	1 PC
8	WOOD DOWEL M8 x 30MM		2 PCS
9	WOOD BUTTON DIA 13.5MM	Ø	2 PCS
10	JCBC BOLT M6 x60mm		8 PCS



Read this instruction carefully. See hardware and furniture part list for guidance.

Be sure all parts are complete, before you assemble. Place all wooden furniture


CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

parts on a clean and flat soft surface to prevent from being scratched.

3. Keep all hardware parts out of reach of children.



2 OF 6

