Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

		PART LIST			
)	ITEM	DESCRIPTION	BOX	QTY	
	Α	STOOL	1	1PC	
	В	LEG	1	3 PCS	L
					l

HARDWARE LIST (BOX : 1)				
ITEM	DESCRIPTION	QTY		
1	JCBC BOLT M6 x 40mm	6 PCS		
2	M6 SPRING WASHER	6 PCS		
3	M4 ALLEN KEY (BALL SHAPE)	1 PC		

- CAUTIONS: 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.
  - 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
  - 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provided).

