## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

## CAUTIONS:

- 1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
- 2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
- 3. Keep all hardware part out of reach of children.

PART LIST			
ITEM	DESCRIPTION	QTY	
А	BACK REST	1 PC	
В	SIDE RAIL - L & R	2 PCS	
С	CUSHION SEAT	1 PC	
D	FRONT LEG	1 PC	
Ε	SIDE STRETCHER	2 PCS	

HARWARE LIST			
ITEM	DESCRIPTION	QTY	
1	JCBC SCREW M6 x 50MM	6 PCS	
2	SPRING WASHER 1/4"	6 PCS	
3	FLAT WASHER 13MM	6 PCS	
4	ALLEN KEY (M4) LONG	1 PC	
5	CSK SCREW M4 x 32MM ← CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC	8 PCS	

