ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTION: 1. Do not FULLY - TIGHTEN the nuts or nuts bolts until they are ready for assembly.

2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tools needed: Screwdriver (not provided).

PART LIST				
ITEM	DESCRIPTION	BOX	QTY	
Α	CHAIR BACK	1	1 PC	
В	SEAT FRAME	1	1 PC	
С	ARM L/R	1	2 PCS	
D	CUSHION	1	1 PC	

HARDWARE LIST (BOX : 1)					
ITEM	DESCRIPTION		QTY		
1	JCBC BOLT M6 x 35mm	 ⊕	2 PCS		
2	JCBC BOLT M6 x 60mm	••••••••••••••••••••••••••••••••••••••	4 PCS		
3	JCBC BOLT M6 x 80mm		2 PCS		
4	JCBC BOLT M6 x 90mm	••••••••••••••••••••••••••••••••••••••	2 PCS		
5	M6 FLAT WASHER	0	10 PCS		
6	M6 SPRING WASHER	0	10 PCS		
7	WOOD SCREW M4 x 32mm	400000	9 PCS		
8	WOOD DOWEL M12 x 30mm		2 PCS		
9	M4 ALLEN KEY (BALL SHAPE)	>	1 PC		







