Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete before assembly. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

	PART LIST				
	ITEM	DESCRIPTION	BOX	QTY	
	Α	STOOL	1	1 PC	L
	В	LEG	1	4 PCS	L
,					ı

	HARDWARE LIST (BOX : 1)						
Y	ITEM	1 DESCRIPTION					
)	1	JCBC BOLT M6 x 50mm	<del></del> (-)	8 PCS			
s	2	M6 FLAT WASHER	0	8 PCS			
	3	M6 SPRING WASHER	0	8 PCS			
	4	WOOD DOWEL M8 x 30mm		4 PCS			
	5	M4 ALLEN KEY (BALL SHAPE)	>	1 PC			

CAUTION: 1. Do not FULLY - TIGHTEN the nuts or nuts bolts until they are ready for assembly.

2. Do not OVER - TIGHTEN the nuts or bolts to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.



