




Top Board




Bottom




Left Side Panel




Right Side Panel




Left Middle Wall




Right Middle Wall




Left Side Door




Right Side Door




Middle Door




2 Side Adjustable Shelf



2 Middle Adjustable Shelf



Back Panel





Glass




Foot


This illustration shows how the CAM fastening system works.




Cam Lock




Cam Bolt




Wooden Dowel




Knob




Shelf Support




Catch



Hinge




Hinge




Jig




Leveling Glide




3/5" Pan Head Screw



3/5" Pan Head Screw







1" Screw













5/8" Flat Head Screw



1




2







Proper orientation of CAM LOCK



Proper orientation of CAM LOCK

