







Assembly Instructions

TB372

Ax1	Bx4	Cx16	Dx16	Fx1	Gx4
					
		Ex16	