

How to adjust the handrest



Place your hand by the middle of the handrest, then press down, you should hear a 'click' sound.

You may press both of your hands by the middle of the handrest, incase the pressure is not enough

To release the handrest.



Lift the handrest all the way up, and release.



Lift the handrest, and adjust to the desire level.