

PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the uphols tery.



A:3PCS



D:2PCS



G:1PC





B:3PCS



C:2PCS



E:1PC



F:1PC



H:2PCS



I:4PCS




M6*15 K:8PCS



L:1PC


Do not fully tighten bolts until assembly is complete.


1. Assemble the chair arms (A) and (B) to the seat (D) and the backrest (C), using bolts and washer (J).




Do not fully tighten bolts until assembly is complete.

2. Assemble the sofa arms (A) and (B) to the seat (F) and the backrest (E), using bolts and washer (J).







3. Assemble the table leg (H) to the table top (G) ,using bolts and washer (k).

