ASSEMBLY INSTRUCTIONS

MODEL: HUDSON CHAIR

Read this instruction carefully. Remove all wrapping material, staples and straps from the carton. See hardware and furniture part list for guidance.


Be sure you have all wooden furniture parts on a clean and flat soft surface, such as a carpet or rug, to prevent from being scratched.


CAUTION:


- 1. Do Not FULLY TIGHTEN the nut or screw until all is ready to assemble.
- 2. Do Not OVER TIGHTEN the nut or screw to avoid causing damages to the tread.
- 3. Keep all hardware part out reach of children.


Part List				
No.	Description	Qty		
Α	Backrest	1 pc		
В	Seat	1 pc		
С	Left Leg	1 pc		
D	Right Leg	1 pc		
Е	Front apron	1 pc		
F	Back apron	1 pc		


Hardware List					
No.	Description		Qty		
1	JCBC M6 x 35mm		8 pcs		
2	Spring Washer M6		8 pcs		
3	CSK M4 x 32mm	Tanama (f)	4 pcs		
4	Allen Key M4 x 110mm		1 pc		
5	Felt Pad		4 pcs		
6	Wood Button 13.5		4 pcs		
7	Dowel		2 pcs		












ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTION

Please read instructions carefully. Remove all wrapping material, staples and packing straps from the carton. Be sure you have all parts before you start assembling. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

CAUTION: 1)DO NOT FULLY TIGHTEN THE NUTS OR SCREWS INITIALLY UNTILL ALL THE NUTS AND 2)SCREWS ARE ASSEMBLED. TO AVOID CAUSING DAMAGE TO THE TREAD, DO NOT OVER-TIGHTEN THE NUTS OR SCREWS.

KEEP ALL HARDWARE PARTS OUT OF RECH OF CHILDREN.

PARTS LIST

NO	DESCRIPTION	QTY
Α	TABLE TOP	1
В	TABLE LEG	4

HARDWARE LIST

NO	DESCRIPTION		QTY	
1	JCBB BOLT M8 x 80mm	6	8	
2	SPRING WASHER M8	0	8	
3	FLAT WASHER M8 x 22mm	0	8	
4	ALLEN KEY M5 x 60mm		1	

