








Assembly Manual



PART LIST

			
A	B	C	D
1 PC	4 PCS	1PC	4PCS



4

⚠ WARNING

Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.