Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


PART LIST				ı
ITEM	DESCRIPTION	BOX	QTY	
Α	CHAIR	1	1 PC	ŀ
В	LEG	1	4 PCS	

HARDWARE LIST (BOX :1)			
ITEM	DESCRIPTION		QTY
1	JCBB BOLT M8 x 50mm	aaaaa⊏()	8 PCS
2	M8 FLAT WASHER	0	8 PCS
3	M8 SPRING WASHER	0	8 PCS
4	M5 ALLEN KEY (BALL SHAPE)	ſ	1 PC

- CAUTION: 1. Do not FULLY TIGHTEN the nuts or nuts bolts until they are ready for assembly.
 - 2. Do not OVER TIGHTEN the nuts or bolts to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


Tools needed: Screwdriver (not provided).



STEP 3

Place the chair on the flat surface and adjust the alignment and balance of the legs then, Please screw tight the steps 1 bolts.





Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.


A CHAIR 1 1 PC	PART LIST				
11 0111111	ITEM	DESCRIPTION	BOX	QTY	
B	Α	CHAIR	1	1 PC	
B LEG 1 4 PC	В	LEG	1	4 PCS	

		HARDWARE LIST (BC	X :1)	
l	ITEM	DESCRIPTION		QTY
	1	JCBB BOLT M8 x 50mm	aaaaa⊏()	8 PCS
	2	M8 FLAT WASHER	0	8 PCS
	3	M8 SPRING WASHER	0	8 PCS
	4	M5 ALLEN KEY (BALL SHAPE)	ſ	1 PC

- CAUTION: 1. Do not FULLY TIGHTEN the nuts or nuts bolts until they are ready for assembly.
 - 2. Do not OVER TIGHTEN the nuts or bolts to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.


NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.


Tools needed: Screwdriver (not provided).



STEP 3

Place the chair on the flat surface and adjust the alignment and balance of the legs then, Please screw tight the steps 1 bolts.





ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

PART LIST		
ITEM	DESCRIPTION	QTY
Α	TABLE TOP	1 PC
В	LEGS	4 PCS

	PART LIST			
ITEM	DESCRIPTION		QTY	
1	JCBC BOLT M6 x 60mm		8 PCS	
2	M6 FLAT WASHER	0	8 PCS	
3	M6 SPRING WASHER		8 PCS	
4	M4 ALLEN KEY	<u> </u>	1 PC	

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

