

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

PART LIST			
ITEM	DESCRIPTION	BOX	QTY
A	HEADBOARD	1	1 PC
B	FOOTBOARD	2	1 PC
C	SIDE RAIL	2	2 PCS
D	CENTER RAIL	2	2 PCS
E	CENTER SUPPORT LEG	2	6 PCS
F	BED SLAT	2	1 SET


HARDWARE LIST (BOX :2)			
ITEM	DESCRIPTION		QTY
1	WOOD SCREW M4 x 38mm		12 PCS
2	WOOD SCREW M4 x 20mm		4 PCS
3	M5 ALLEN KEY (BALL SHAPE)		1 PC

CAUTIONS :

1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.
Tool needed : Screwdriver (not provider).

STEP 1




Loosen the pre-inserted bolt on the headboard and footboard using Allen key ball shape (3).

STEP 2




ASSEMBLY INSTRUCTIONS


STEP 3




STEP 4



STEP 5



STEP 6



*** When moving the bed position, the center support legs must be adjust to be straight to avoid any broken problem.**