



9028 4 Drawer Chest


Assembly Instructions

WI-1225



Note: Do not assemble using power tools. This can cause the bolts to be overtightened

WARNING



Anti Tipping Kit
Anti Tipping Kit x 1



Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb, or hang on any drawers, doors or shelves.
- NEVER open more than one drawer at a time.
- DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.
- Place heaviest items in the lowest drawer.









9028 4 Drawer Chest

Assembly Instructions





WI-1225

1 Parts List

Parts in Box A:



Parts in Box B:




9028 4 Drawer Chest


Assembly Instructions

WI-1225

2 Hardware List



3 Assemble the Drawer Sides (O & P) & Drawer Rail (K) to the Drawer Face (J).




9028 4 Drawer Chest

Assembly Instructions

WI-1225


- 4** Slide the Drawer Bottom (H) into the groove on the Drawer Sides (O & P).

x 4




- 5** Assemble the Drawer Back (G) to the Drawer Sides (O & P). Fit the Handles to the Drawer Face (J).

x 4



- 6** Turn the Drawer over to fit angled 25mm Wood screws (5) to the Drawer Rail (K).

x 4




9028 4 Drawer Chest

Assembly Instructions

WI-1225

- 7** Fit the 'L' Bracket (8) to the Side Panel (M & N).



- 8** Assemble the Top Panel (A) to the Side Panel (M & N).




9028 4 Drawer Chest


Assembly Instructions

WI-1225

- 9** Fit the Support Bar Upper & Bottom (D, E & F) to the Side Panel (M & N) as shown.



- 10** Assemble the Bottom Support (L) to the Bottom Front & Rear Support Bar (E & F) as shown.




9028 4 Drawer Chest


Assembly Instructions

WI-1225

- 11** Bolt the Bottom Support (L) to the Bottom Panel (B) as shown.



- 12** Attached the Back Panel (C) to the back of the frame.




9028 4 Drawer Chest


Assembly Instructions

WI-1225

13 Install the Drawer.




- Push the interlock bar **upwards** before inserting the drawers.




14 Fit and adjust the Drawer Face (J).

* NOTE: Before fitting the Wood Screws.
Loosen the JCBs on the Drawer Face if
the face needs alignment.



* NOTE: Only one drawer
can be open at a time.





9028 4 Drawer Chest

Assembly Instructions


WI-1225

- 15** After the Drawer Faces (J) are aligned, secure with wood screws.

* NOTE: Only one drawer can be open at a time.



- 16** Remove the Drawers.



- After removing the top drawer, push the interlock bar **down**. Then remove the lower drawers.

