WI13144





Ax12	 Bx12	Cx8	Dx8
 Ex4	 Fx4	 Gx4	 Hx8
Ix8	Jx4	 Kx2	Lx4

Step 1



	Dx8
	Ex4

Stretch Hardware E and fix it to Part 2&3 with D

Step 2



	Ax4
	Bx4
	Cx4

Connect Part 1 to 2&3 with Hardware C&B and lock them with A
(Screw A tight clockwise)

Step 3



Insert Part 5 along the slots of 3&2 into 1

Step 4



	Cx4
	Fx4

Lock Part 4 to 3&2 with Hardware C&F

Step 5



Gx4	Connect Part 13 to 11&12 with Hardware G

Step 6



Hx8	Lock the frame to Part 4 with Hardware H

Step 7





Connect Part 9 to 7&8 with Hardware I
Insert Part 10 along the slots of 7&8 into 9
Install Hardware K on Part 6 with J and fix B to 6
Lock Part 6 to 7&8 with Hardware A (Screw A tight clockwise)

	Ax8		
	Bx8		Jx4
	Ix8		Kx2

x2

Step 8







Pull out Hardware E (drawer slide) and install drawers with L

	Lx4