









ASSEMBLY INSTRUCTION

MODEL: CF 8825-C (4'6")








Step 1: Attach the back side rail (F) and middle panel (E) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).

Step 2: Attach the back panel (B) to arm (A). Attach front side rail (D) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).


A		1 pc
B		1 pc
C		1 pc
D		1 pc
E		1 pc
F		1 pc



Packing Hardware

1		1 pc
	M5 x 70 mm	
2		1 pc
	M5 x 65 mm	
3		26 pcs
	CSK M4 x 32mm	
4		16 pcs
	JCBB M8 X 20	
5		4 pcs
	JCBC M6 X 50	
6		4 pcs
	SPRING WASHER	
7		4 pcs
	FLAT WASHER	

Step 3: Tighten the slats with CSK screw (3). The distance of the slats should be sufficient to obtain desirable bed stability.











ASSEMBLY INSTRUCTION

MODEL: CF 8825-C (5')

Step 1: Attach the back side rail (F) and middle panel (E) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).

Step 2: Attach the back panel (B) to arm (A). Attach front side rail (D) to arm (A) by pushing the bracket down to fit it. Tighten with Allen Key (1).








A		1 pc
B		1 pc
C		1 pc
D		1 pc
E		1 pc
F		1 pc



BACK VIEW

Packing Hardware

Step 3: Tighten the slats with CSK screw (3). The distance of the slats should be sufficient to obtain desirable bed stability.

1		1 pc
2		1 pc
3		28 pcs
4		16 pcs
5		4 pcs
6		4 pcs
7		4 pcs

